

CD19-005M Use and Applications

1. General guidelines

Use a magnetic separator that is suitable for your equipment and application. Allow the beads to separate for at least 1 minute before removing supernatant. The beads are dense and will tend to settle very quickly. Be sure that any bead mixture is homogenous before aliquoting.

Before any experiment, it is necessary to wash the magnetic beads and remove the trehalose from the formulation buffer and change the buffer to your Assay/Washing Buffer.

1. Place the tube with reconstituted beads on a magnetic separator for 2 min. Remove the supernatant.

2. Remove the tube from the magnetic separator and resuspend the pelleted beads in equal volume (or at least 1000µL) of Assay/Washing Buffer. Mix by vortex for approximately 10 sec.

3. Place the tube on the magnetic separator for 2 min. Remove the supernatant.

4. Wash the beads for three times in total by repeating steps 2 and 3.

2. Binding assay

Below is a suggested antibody capture protocol for your reference.

1. Reconstitute and wash the magnetic beads according to the Certificate of Analysis. Immediate use is strongly recommended.

2. Add 1mL Assay/Washing Buffer per mg Beads to resuspend the beads. The most common Assay/Washing Buffer is PBS, pH 7.3, with 0.05% Tween-20. Optionally, you may add 0.05% BSA. When assaying a serum sample, please choose a Special Assay/Blocking Buffer to minimize the background signal.

3. Sample Dilution: Dilute your antibody of interest from 20µg/mL to 0.039µg/mL in Assay buffer.

4. Add 100 μL beads to each tube or plate well. Place the beads on the magnetic separator for 1-2 min. Remove the supernatant.

5. Add 100 μ L diluted sample to the pelleted beads, and mix the beads with samples by mixer. Add 100 μ L of assay buffer as a blank control into wells containing the beads.

6. Cover the tubes on a rotator or place the plate on a plate mixer and incubate for 60 minutes at room temperature. Alternatively, rotate overnight at 4°C.

7. Place the tube/plate on the magnetic separator for 2 min. Remove the supernatant.

8. Remove the tube/plate from the magnetic separator and resuspend the pelleted beads in 200 μ L of Assay/Washing Buffer by a vortex.

9. Wash the beads for a total of 4 times by repeating steps 7–8. After the last wash, remove the supernatant.

10. Dilute your Secondary Antibody in Assay buffer. Add 100µL secondary antibody (at an appropriate dilution

Fax: 1-631-938-8127

Email: info@creative-biomart.com

USA: 1-631-559-9269 1-516-512-3133 Europe: 49-179-397-5992

45-1 Ramsey Road, Shirley, NY 11967, USA



ratio) to the beads. We recommend PE anti-Human IgG Fc (Biolegend, Cat. No. 409304) at 1:200 to detect your human IgG antibody samples. Any other fluorescent-labeled secondary antibody is appropriate.

11. Place the tubes on a rotator or place the plate on a plate mixer, and incubate for 60 minutes at room temperature. Cover with foil to avoid photobleaching.

12. Repeat steps 7-8 for a total of four washes with Assay/Washing buffer. After the last wash remove the supernatant.

13. Add 100 μ L of Assay/Washing Buffer to the beads, and resuspend the Beads.

14. Transfer the 100µL beads into a 96-well black plate that is compatible with your plate reader. Keep the beads well suspended.

15. Read the plate at excitation 488 nm/emission 575 nm on a plate reader within 10 min (Avoid the precipitation of the beads).



🖶 Fax: 1-631-938-8127

Email: info@creative-biomart.com