

Thrombin Activity Fluorometric Assay Kit

Product Information

Cat.No. Kit-0338

Product Overview

Thrombin activity assay kit utilizes the ability of Thrombin to proteolytically cleave a synthetic substrate and release a fluorophore, AMC, which can be easily quantified by fluorescence reader. This assay kit is simple, rapid and can detect Thrombin activity as low as 1 ng in samples.

Applications

Determine activity of pure Thrombin
Detect the activity of Thrombin in plasma

Storage

Store kit at -20°C, protected from light. Briefly centrifuge small vials at low speed prior to opening. Read entire protocol before performing the assay.

Thrombin Assay Buffer: Bring to room temperature before use.

Thrombin Enzyme Standard: Prepare a stock solution of Thrombin Enzyme (50 ng/μl) by adding 12 μl of Thrombin Dilution buffer to 4 μl of Thrombin Enzyme Standard. Mix. Aliquot & store at -80°C. Avoid repeated freeze/thaw.

Size

100 assays

Kit Components

Thrombin Dilution Buffer 1 ml
Thrombin Assay Buffer 15 ml
Thrombin Enzyme Standard 5 μl
Thrombin Substrate 0.5 ml

Materials Required but Not Supplied

96-well microplate with flat bottom. White plate is preferred for this assay.
Fluorometer



Thrombin Activity Fluorometric Assay Kit

Assay Protocol

1. Sample Preparation: Add 2-50 μl of sample containing Thrombin per well of 96-well plate and adjust the volume to 50 μl with Thrombin Assay Buffer.
2. Standard Curve Preparation: Dilute Thrombin Enzyme Standard to 2.5 ng/ μl by adding 38 μl of Thrombin Dilution Buffer to 2 μl of Thrombin Enzyme stock solution (50 ng/ μl). Mix and add 0, 2, 4, 6, 8 and 10 μl of diluted Thrombin Enzyme Standard (2.5 ng/ μl) into a series of wells in a 96-well plate. Adjust the volume to 50 μl with Thrombin Assay Buffer to prepare 0, 5, 10, 15, 20 and 25 ng/well of Thrombin Enzyme Standard.

Note: Store the diluted Thrombin Enzyme Standard solution at -80°C .

3. Substrate Mix: Prepare enough reagents for the number of assays to be performed. Prepare 50 μl of Substrate Mix for Standard & sample wells.

Thrombin Assay Buffer 45 μl

Thrombin Substrate 5 μl

Mix and add 50 μl of Thrombin Substrate Mix into Standard and sample well(s). Mix well.

4. Measurement: Measure fluorescence in kinetic mode for 30-60 min. at 37°C (Ex/Em = 350/450 nm). Choose two time points (T1 & T2) in the linear range of the plot and obtain the corresponding values for the fluorescence (RFU1 and RFU2).

5. Calculations: Subtract 0 Standard reading from all readings. Plot the Thrombin Standard Curve. Apply sample's ΔRFU to Thrombin Standard Curve to obtain corresponding Thrombin (B, in ng) and calculate the activity of Thrombin in the sample as:

Sample Thrombin Activity = $B/V * \text{Dilution factor} = \text{ng/ml} = \text{ug/L}$

Where B is Thrombin amount from Standard Curve (ng)

V is sample volume added into the reaction well (ml)
